



ADVANCE®

WATERBORNE INTERIOR ALKYD PEARL K792

Features

- Excellent durability
- Excellent flow and levelling properties
- Extended open time
- Minimal yellowing
- Spatter resistant
- Easy application
- Easy clean up
- Block resistant

Recommended For

Ideal for interior doors, trim, cabinets, walls and ceilings. For primed or previously painted wallboard, plaster, masonry, wood and metal.

General Description

A premium quality, waterborne alkyd enamel that delivers the desired flow and levelling characteristics of conventional alkyd paint. It provides a tough, pearl finish that stands up to repeated washing. It is easy to apply, resists spattering and cleans up with soap and water.

Limitations

- Depending on weather and drying conditions, it could take up to 30 days to reach optimum hardness and final sheen.
- Sand glossy alkyds before applying ADVANCE.

Product Information		
Colours — Standard: White (01), Black (80)	Technical Data[◇]	
	Pastel Base	
	Vehicle Type	Waterborne Alkyd
— Tint Bases: Benjamin Moore® Gennex® Bases 1X, 2X, 3X, 4X	Pigment Type	Titanium Dioxide
	Volume Solids	39%
	Coverage per 3.79 L at Recommended Film Thickness	37.1 – 46.4 sq. m. (400 – 500 sq. ft.)
— Special Colours: Contact your Benjamin Moore representative.	Recommended Film Thickness	– Wet 3.6 mils – Dry 1.35 mils
	Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure colour uniformity and minimize the disposal of excess paint. See chart on page two.	
	Dry Time @ 25 °C (77 °F) @ 50% RH	– To Touch 4-6 Hours – To Recoat 16 Hours
Certifications & Qualifications: VOC compliant in all regulated areas Qualifies for LEED® v4 Credit Qualifies for CHPS low emitting credit (Collaborative for High Performance Schools) CDPH v1 Emission Certified Class A (0-25) over non-combustible surfaces when tested in accordance with ASTM E-84 Water Vapor Transmission: ASTM D1653 (method A): 2.55 perms	Advance's® full hardness and adhesion develop over time. Do not expose to heavy abrasion or return shelves/tabletops to service for at least 5-7 days to prevent damage to the finish. High humidity or cooler temperatures will prolong dry, recoat and cure times.	
	Dries By	Evaporation, Oxidation
	Viscosity	95 ± 5 KU
Customer Service Information Centre: 1-800-361-5898, info@benjaminmoore.ca , www.benjaminmoore.ca	Flash Point	None
	Gloss / Sheen	Pearl (25-35 @ 60°)
	Surface Temperature at Application	– Min. 10 °C (50 °F) – Max. 32 °C (90 °F)
	Thin With	Clean Water
	Clean Up Thinner	Clean Water
	Weight Per 3.79 L	4.9 kg (10.9 lbs)
	Storage Temperature	– Min. 4.4 °C (40 °F) – Max. 32 °C (90 °F)
	Volatile Organic Compounds (VOC)	
	48 g/L	
	[◇] Reported values are for Pastel Base. Contact Benjamin Moore for values of other bases or colours.	

ADVANCE® Waterborne Interior Alkyd Pearl K792

Surface Preparation

Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water-soluble materials, and mildew. Remove any peeling or scaling paint and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free of sanding dust.

New plaster or masonry surfaces must be allowed to cure before applying base coat. Cured plaster should be hard, have a slight sheen and maximum pH of 10; soft, porous or powdery plaster indicates improper cure. Never sand a plaster surface; knife off any protrusions and prime plaster before and after applying patching compound. Poured or pre-cast concrete with a very smooth surface should be etched or abraded to promote adhesion, after removing all form of release agents and curing compounds. Remove any powder or loose particles before priming. Wood substrates must be thoroughly dry.

Difficult Substrates: Benjamin Moore offers a number of specialty primers for use over difficult substrates such as bleeding woods, grease stains, crayon markings, hard glossy surfaces, galvanized metal, or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore retailer can recommend the right problem solving primer for your special needs.

Note: Although Advance yellows less than conventional alkyds, a slight amount of yellowing may occur. This effect is accelerated in dark or poorly ventilated areas and is more visible in lighter colours.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by logging onto Health Canada @ <https://www.canada.ca/en/health-canada/services/environmental-workplace-health/environmental-contaminants/lead/lead-information-package-some-commonly-asked-questions-about-lead-human-health.html>

Primer/Finish Systems

New surfaces should be fully primed, and previously painted surfaces may be primed or spot primed as necessary. For best hiding results use Benjamin Moore® ADVANCE® Waterborne Interior Alkyd Primer (K790) tinted to the approximate finish coat colour. **Special Note:** Certain custom colours require a Deep Colour Base Primer tinted to a special prescription formula to achieve the desired colour. Consult your Benjamin Moore retailer.

Wood and engineered wood products:

Primer: ADVANCE® Waterborne Interior Alkyd Primer (K790), Fresh Start® Multi-Purpose Latex Primer (F023) or Fresh Start® Multi-Purpose Oil Based Primer (F024)

Finish: 1 or 2 coats of ADVANCE® Waterborne Interior Alkyd Pearl (K792)

Cabinetry-All surfaces to be roughened by sanding (220 grit or coarser) before priming; light sanding between coats allows for a smoother finish; all dust must be cleaned.

Wood, MDF & Thermofoil

Primer: ADVANCE® Waterborne Interior Alkyd Primer (K790)

Finish: 1 or more coats of ADVANCE® Waterborne Interior Alkyd Pearl (K792)

Laminate (Formica)

Primer: Fresh Start® High-Hiding All Purpose Primer (K046)

Finish: 1 or more coats of ADVANCE® Waterborne Interior Alkyd Pearl (K792)

Plastic (Vinyl) veneer

Primer: 1 coat of ADVANCE® Waterborne Interior Alkyd Primer (K790) after removing plastic veneer by sanding away (an electric sander with a 100 grit paper works fine; manual sanding may need to be vigorous)

Finish: 1 or more coats of ADVANCE® Waterborne Interior Alkyd Pearl (K792)

Drywall:

Primer: ADVANCE® Waterborne Interior Alkyd Primer (K790) or Fresh Start® Multi-Purpose Latex Primer (F023)

Finish: 1 or 2 coats of ADVANCE® Waterborne Interior Alkyd Pearl (K792)

Plaster:

Primer: Fresh Start® Multi-Purpose Latex Primer (F023) or Fresh Start® High-Hiding All Purpose Primer (K046)

Finish: 1 or 2 coats of ADVANCE® Waterborne Interior Alkyd Pearl (K792)

Rough or Pitted Masonry:

Primer: Ultra Spec® Masonry Interior/Exterior Hi-Build Block Filler (K571)

Finish: 1 or 2 coats of ADVANCE® Waterborne Interior Alkyd Pearl (K792)

Smooth Poured or Pre-cast Concrete:

Primer: Ultra Spec® Masonry Interior / Exterior 100% Acrylic Masonry Sealer (K608) or Fresh Start® 100% Acrylic All Purpose Primer (F023)

Finish: 1 or 2 coats of ADVANCE® Waterborne Interior Alkyd Pearl (K792)

Ferrous Metal (Steel and Iron):

Primer: Ultra Spec® HP Acrylic Metal Primer (FP04) or Super Spec HP® Alkyd Metal Primer (KP06)

Finish: 1 or 2 coats of ADVANCE® Waterborne Interior Alkyd Pearl (K792)

Non-Ferrous Metal (Galvanized & Aluminum):

All new metal surfaces must be thoroughly cleaned with Corotech® Oil & Grease Emulsifier (V600) to remove contaminants. New shiny non-ferrous metal surfaces that will be subject to abrasion should be dulled with very fine sandpaper or a synthetic steel wool pad to promote adhesion

Primer: Ultra Spec® HP Acrylic Metal Primer (FP04)

Finish: 1 or 2 coats of ADVANCE® Waterborne Interior Alkyd Pearl (K792)

Hard Glossy Alkyd Surfaces:

Abrasion by sanding required for optimum adhesion.

Repair, All Substrates: Prime bare areas with the primer recommended for the substrate above. Sand glossy alkyds before applying ADVANCE®.

Application

Stir thoroughly before and during use. Apply one or two coats.

Paint Application: For best results, use a premium Benjamin Moore® custom-blended nylon/polyester brush, premium Benjamin Moore® Microfibre roller, or a similar product. Apply paint generously from unpainted area into wet area. This product can also be sprayed.

Extra ventilation is necessary under humid conditions to speed the dry time of ADVANCE®, especially when the paint is applied over sealed, hard, non-porous surfaces. The chart below is for general guidance.

Mild conditions	Severe conditions	Very severe conditions
Dry (RH < 50%), and temperature between 21 °C (70 °F) and 32 °C (90 °F)	(RH > 50%), and/or temperature between 10 °C (50 °F) and 21 °C (70 °F)	RH > 85%, or temperature <10 °C (50 °F)
ADVANCE® will dry normally. Dry to touch: 4-6 hours To Recoat: 16 hours	ADVANCE® will dry slower than normal unless the following is done to speed the dry time: Ventilate the room with a fan and/or turn on A/C to lower the humidity.	Do not apply ADVANCE®.

Spray, Airless: Fluid Pressure: 1,500 - 2,500 psi
Tip: 0.011 - 0.015

Thinning/Clean up

Thinning is unnecessary, but if required to obtain desired application properties, a small amount of clean water may be added. Never add other paints or solvents. Clean up with warm soapy water. Brushes and rollers should be given a final rinse with mineral spirits to remove residual alkyd. Spray equipment should be given a final rinse with mineral spirits to prevent rusting.

Environmental Health & Safety Information

May cause allergic skin reaction.

Do not get on skin or clothing

Use only in a well ventilated area. Keep container closed when not in use. In case of spillage, absorb with inert material and dispose of in accordance with local regulations. Wash thoroughly after handling.

**KEEP OUT OF REACH OF CHILDREN
PROTECT FROM FREEZING**

**Refer to Safety Data Sheet for additional
health and safety information.**

Benjamin Moore & Co., Ltd. 8775 Keele St., Concord, ON L4K 2N1 1-800-361-5898 www.benjaminmoore.ca M72 K792 CE 021918

ADVANCE, Benjamin Moore, Fresh Start, Gennex, Super Spec HP, Ultra Spec and the triangle "M" symbol are registered trademarks of Benjamin Moore & Co., Ltd. All other marks are the property of their respective owner. This product is not endorsed by or a division of CHPS. This product is provided by Benjamin Moore, not CHPS. ©2010, 2018 Benjamin Moore & Co., Ltd. All rights Reserved